




FTB-301 Parts Diagram



FTB-301 Parts List

ITEM	DESCRIPTION / OEM PART #
K3	Discharge Relay, 120V, 8328802
K2	Mode Relay, 24V, 8328801
SW1	Interlock Switch, 4901220
VR1	Suppressor, 120V, 6901079
T102	Coupling Transformer, 8336702
T1	Power Transformer (-43E), 8841201
T101	Trigger Transformer, 8288201
FH306/308, RC102	Resistor Network, 8403407
FH306/308, RC101	Resistor Network, 8403403
	Photocell, Resistive, 1855001
C3	Burst Capacitor, 0.5uF, 6848201
C3	Burst Capacitor, 1uF, 6848202
C4	Tuning Capacitor, 3uF, 6577903
C1	Day Capacitor, 70uF, 6720401
BR1	Diode Bridge, 6902806
FT101	Flash Tube, 8384328
F1	Power Fuse, 4900307
PCB2	High Voltage Rectifier Board, 8458001
PCB1	Trigger Board, 24063xx
	Trigger Board (120V PEC),
	Trigger Board (Resistive, PEC),
PCB4	Sense Module, 2811101
R1	Bleed Resistor, 6900541
R2	Burst Resistor, 6900532