


# FTB-312 Parts Diagram



## FTB-312 Parts List

ITEM	DESCRIPTION / OEM PART #
C3	Burst Capacitor, 0.5uF, 6848201
C3	Burst Capacitor, 1uF, 6848202
C4	Tuning Capacitor, 3uF, 6577903
C2B	Capacitor, 40uF, 6386503
C2A, C2C, C2D	Day Capacitor, 70uF, 6720401
BR1	Diode Bridge, 6902806
FT101	Flash Tube, 8384308
F5, F6	Fuse, 4900337
F1	Marker Fuse, 4900345
F1	Power Fuse, 4901931
L1	Burst Choke, 4860601
PCB2	High Voltage Rectifier Board, 8458001
PCB1	Timing & Trigger Board, 24740xx
PCB1	Trigger Board for AutoDialer Pro, PCB1
PCB1	*Refurbished OEM 4747 Board, 24747xx
PCB4	Sense Module, 2811101
LS1	Filter Detection Board, 2804001
LS1	Telephone Line Surge Suppressor, 2865301
HV	High Voltage Warning Lamp, 4902317

ITEM	DESCRIPTION / OEM PART #
------	--------------------------

R1	Bleed Resistor, 6900541
R2	Burst Resistor, 6900532
K5	Marker Relay, 4902617
K3	Discharge Relay, 120V, 8328802
K2	Mode Relay, 24V, 8328801
SW1	Interlock Switch, 4901220
VR1	Suppressor, 120V, 6901079
T102	Coupling Transformer, 8336702
T1	Power Transformer (-43E), 8841201
T101	Trigger Transformer, 8288201
FH306/308, RC102	Resistor Network, 8403407
FH306/308, RC101	Resistor Network, 8403403
	Photocell, Resistive, 1855001
	Actuator Assembly